Antelope Elementary (Water Boiler)

Write down the number for pressure and temp, not just an "X"

					ou '	write	down the work or			
Initials	Twice D	aily	Daily				Twice Daily		Daily	
	Boiler Pressure (0-30 lbs)	Boiler Temp. (80- 190)	Air Comp. Pressure, # on the gauge & operation	Walk-in Freezer & Cooler			Boiler Pressure (0-30 lbs)	Boiler Temp. (80- 190)	Air Comp. Pressure, # on the gauge & operation	Walk-in Freeze & Cooler
am pm					17	am pm				
am						am				
2 pm					18					
am					19	am				
3 pm						pm				
am						am				
4 pm					20	pm				
am					21	am				
5 pm						pm				
am					22	am				
pm						pm				
am 7					23	am				
pm						pm				
am 8					24	am				
pm						pm				
am 9					25	am				
pm						pm				
am					26	am				
pm						pm				
am 11					27	am				
pm						pm				
am					28	am				
pm						pm				
13 am					29	am				
pm						pm				
am 14					30	am				
pm						pm				
15 am					31					
pm						pm st this r	eport in the boiler roc	m & write vour fir	ndings daily or as	indicated. At the
16 am					en	d of the	e month, share with yo			
pm						fax to 2	7881. Port throughout the ve			

Each individual boiler requires a separate report throughout the year.

The Boiler Room is <u>NOT</u> to be used for storage. Keep <u>ALL COMBUSTIBLE MATERIAL OUT</u> of the room! Nightly Lock-Up: Ensure the boiler is on prior to locking up for the night.

Boiler#	Boiler Room Inspection R		School Antelope El Month/Year								
	Water Boiler	ivioritri/ Year									
Every Week											
1st Week	2nd Week	3rd Week	4th Week								
1 Observe boiler through firing cycle											
Record expansion tank's water level. (1/4, 1/3, 1/2)											
a) Check air compressor oil level											
Check heating pumps for:											
a) bearing noise											
b) leaking seals											
c) correct pressure											
Check domestic hot water pumps for:											
a) Broken couplers											
5 b) Motor mounts											
c) Leaks											
Sweep floor, dust											
6 equipment & piping.(If not											
asbestos) _ Check & write down water											
7 meter reading.											
	Every Month										
Oil domestic hot water											
pumps & motors Flush down low water cut-											
off.											
Check for leaks on heating											
3 equipment & associated											
piping.											
Check digital reading on water heater for error											
4 codes & temps. In excess											
of 135. Report any											
problems/concerns.											
5 Blow down mud legs (not glycol boilers)											
6 Emergency lights in bldg.											
7 Gen. radiator-fluid level											
8 Gen. battery-water level											
9 Gen. engine oil level											
Landa and the same of the	Beginning of month reading: End of month reading:										
10 unit has exercised since	ing of month reading:	Ena of mor	un reauling.								
last month											
Fan Room											
11 Check oil on heat pumps											
Check filters											
Every other month											
1 Check pop-off valve operation											
Concerns/Issues regarding your boiler(s) & room:	Concerns/Issues regarding your boiler(s) & room:										